

Mac Computer instructions to install USB Display Cradle

Apple Macintosh Compatibility

We do not have native Macintosh applications at this time.

Intel based Macs will work with Boot Camp:

1. Install Windows 2000, XP or Vista onto the Mac through the Boot Camp application.
- This allows windows to run native on the hardware (must obtain from Apple Store)
2. Boot into Windows
3. Treat as a normal Windows machine.

NOTE: This will only work on Intel based hardware. G4/G5 machines are not compatible.

NOTE: If the Mac in question has a mouse with a single button, "Right Click" can be accomplished by holding down the [ctrl] key on the keyboard while clicking.

NOTE: The Latest Mac OS "Leopard" includes Boot Camp.

Our applications are not supported on Parallels which is very similar to Virtual PC creating virtual host drivers for XP which runs ontop of OS X.

Thank You!

Supra
A UTC Fire & Security Company
1-877-699-6787
5:00am - 7:00 pm PST

E suprasupport@fs.utc.com
www.supraekey.com
www.utcfireandsecurity.com

4001 Fairview Industrial Dr. SE
Salem, Oregon 97302, United States
UTC Fire & Security